GARDNER DENVER®

15-514
4th Edition
APRIL, 2007

SINGLE ACTING TRIPLEX PUMP

MODEL

PZH

8” STROKE

PARTS LIST

Gardner Denver

MAINTAIN PUMP RELIABILITY AND PERFORMANCE WITH GENUINE GARDNER DENVER® PARTS AND SUPPORT SERVICES

Gardner Denver® genuine pump parts are manufactured to design tolerances and are developed for optimum dependability. Design and material innovations are the result of years of experience with hundreds of different pump applications. Reliability in materials and quality assurance are incorporated in our genuine replacement parts.

Your authorized Gardner Denver distributor offers all the backup you'll need. A worldwide network of authorized distributors provides the finest product support in the pump industry. Your local authorized distributor maintains a large inventory of genuine parts and he is backed up for emergency parts issues with access to Oklahoma City, OK. and the factory in Quincy, IL.

Your authorized distributor can support all your Gardner Denver pump needs.

Trained parts specialists are available to assist you in selecting the correct replacement parts.

ALL ORDERS for PARTS should be placed with the NEAREST Authorized Distributor.

To find your nearest distributor you may use one of the following choices:
* Log onto the Gardner Denver web site: www.gardnerdenver.com
* Send an E-Mail request to: pumps@gardnerdenver.com
* Contact one of our sales offices listed below.

The Gardner Denver Sales Offices are located as follows:

DOMESTIC

Gardner Denver
2200 South Prospect
Oklahoma City, OK. 73129

Phone: (405) 677-5736

Fax: (405) 677-5807

INTERNATIONAL

Gardner Denver
1800 Gardner Expressway
Quincy, IL 62301

Phone: (217) 222-5400

Fax: (217) 223-1581

INSTRUCTIONS FOR ORDERING REPAIR PARTS:

When ordering parts, specify Pump MODEL and SERIAL NUMBER (see nameplate on unit).
The Serial Number is also stamped on top of the frame at the connecting end.
(Between the cradle opening and the fluid cylinder)

SPECIFY THE NUMBER OF PARTS REQUIRED, EXACTLY.

DO NOT ORDER BY SETS OR GROUPS.

To determine the Right Hand and Left-Hand side of a pump, stand at the power end and look toward the fluid end. Right Hand and Left Hand are indicated in parenthesis following the part name, i.e. (RH) and (LH), when appropriate.


For Operating and Service Instructions see:

SERVICE MANUAL 15-600

TABLE OF CONTENTS

Maintain Pump Reliability and Performance with Genuine Gardner Denver Parts and Support Services i
Instructions for Ordering Repair Parts i
Table of Contents ii
Frame Group & Miscellaneous Parts .... 1 & 2
Drive Parts .... 3 & 4
General Service, 5000 PSI, Wide Body™ Fluid Cylinder & Manifolds .... 5 & 6
"Self Adjusting" Oil Stop Head Packing 7
Steel Fitted, Center Guided Valve (General Service)
With Polyurethane Insert 8
With Carboxylated Insert 8
Piston Rod & Coupling for 5000 PSI (Wide Body™) .... 9 & 10
Piston & Liner for 5000 PSI (Wide Body™) .... 9 & 10
Internal Oil Lubrication Piping .... 11 & 12
Sump Oil Filter 13
Sump Oil Circulating Pump 14
Piston Rod Wash Piping – 5000 PSI .... 15 & 16
Piston Rod Wash Pump 17
Heat Exchanger Group (Optional Equipment) 18
Valve Seat Puller (Optional Equipment) 19
Optional Equipment 20

FRAME & MISCELLANEOUS PARTS



Ref Drawing – 318PZG797


FOR LIST OF PARTS SEE PAGE 2

Order by Part Number and Description. Reference Numbers for your convenience only.

FRAME & MISCELLANEOUS PARTS

Ref.No.	Name of Part	Qty.	Part No.
	FRAME ASM, Includes Reference Numbers 1 thru 11	1	PZH74431
1	FRAME	1	200PZH001
2	PLUG, Cradle Drain	1	64AA9
3	STUD, Crosshead Inspection Plate	2	79A238
4	NUT, Crosshead Inspection Plate	2	50B5
5	PLUG	1	64A5
6	PLUG-MAGNETIC, Sump Oil Drain	3	66D13
7	SPACER	2	2012523
8	STUD, Spacer to Frame	4	2012526
9	KEY, Spacer to Frame	4	35C19
10	PLATE, Spacer to Frame	4	2012524
11	NUT, Spacer to Frame Stud	8	50B34
12	GASKET, Crosshead Inspection Plate	2	PZ715
13	PLATE-INSPECTION, Crosshead	2	2012703
14	SCREW, Crosshead Inspection Plate	10	655EE060
15	PLATE-RETAINER	1	200PZH253
16	SCREW, Bearing Retainer Plate	12	655EG050
17	HOUSING-BEARING, Eccentric	2	2012512
18	GASKET, Bearing Cover Plate	2	2012525N
19	PLATE-BEARING COVER (Rigid Side)	1	2012514
20	SCREW, Bearing Cover Plate	48	655EG070
21	GASKET, Inspection Plate	2	25C1788N
22	PLATE-INSPECTION	1	202FXT052
23	SCREW, Inspection Plate	6	655EF050
24	GAUGE, Oil Level Sight	1	40L17
25	GAUGE, Oil Temperature	1	27H11
26	BUSHING-PIPE	1	64E2
27	SLIDE-CROSSHEAD	6	2012509
28	SCREW, Crosshead Slide to Frame	24	75LM6
29	SEAL-FASTENER	12	60DD35
30	LOCKNUT	24	50V44
31	PLATE-BEARING COVER (Floating Side)	1	2012515
32	HOOD, Eccentric	1	2012505
33	SCREW, Hood to Frame	30	655EF050
34	GASKET, Hood	1	2012520
35	BREATHER	1	5C24
36	PLATE, Inspection	1	KXG842
37	GASKET, Inspection Plate	1	25C1818
38	SCREW, Inspection Plate	8	655EF040
39	GASKET, Inspection Plate Screw	8	25F13
40	PLATE-INSPECTION	3	206PZL052
41	GASKET, Inspection Plate	6	25C1839
42	SCREW, Inspection Plate	24	655ED040
43	COVER, Left Side Cradle Area	1	2012598
44	COVER, Middle Cradle Area	1	2012596
45	COVER, Right Side Cradle Area	1	2012597
46	SCREW, Hood to Spacer	4	655EF07
47	Not Used on This Hood		
48	PLUG	4	64A27

DRIVE PARTS




Ref Drawing – 309PZJ797

FOR LIST OF PARTS SEE PAGE 4

DRIVE PARTS

Ref. No.	Name of Part	Qty.	Part No.
1	JACKSHAFT	1	2012507
2	KEY-JACKSHAFT	1	35B380
3	SPACER, Jackshaft Bearing	2	2012522
4	SLEAVE-WEAR	2	2009632
5	GASKET, Bearing Housing to Frame	2	25C1771
6	HOUSING-BEARING	2	KXF368
7	SCREW, Bearing Housing	16	655EG080
8	BEARING-ROLLER, Jackshaft	2	12W58
9	GASKET, Retainer Plate to Bearing Housing	2	25C2562
10	PLATE, Bearing Retainer	2	KXF370
11	PLUG	2	64AA5
12	SCREW, Retainer Plate to Bearing Housing	16	75P95
13	SEAL-OIL	2	2009633
14	ECCENTRIC	1	2012503
15	GEAR-DRIVEN	1	2012508
16	SCREW, Gear to Eccentric	12	75B150
17	WIRE	144”	97A29
18	BEARING-ROLLER, Eccentric	2	12GF38
19	SHIM (.002)	6	2012752
20	SHIM (.005)	6	2012751
21	SHIM (.007)	6	2012750
22	SHIM (.020)	8	2012749
23	PLATE-RETAINER, Eccentric Bearing	2	2012516
24	SCREW, Retainer to Eccentric	12	75B28
25	WIRE	48”	97A29
26	CONNECTING ROD Includes Ref. Numbers. 27 & 28	3	2012506
27	BOLT-CONNECTING ROD	6	2012518
28	NUT, Connecting Rod Bolt	6	50B34
29	BEARING, Connecting Rod to Eccentric	3	12W85
30	RING-RETAINING, Connecting Rod Bearing	1	2009794
31	PLATE-RETAINING, Bearing to Eccentric	14	1PZ1400
32	SCREW, Bearing to Eccentric	14	655EF05D
33	WIRE	384”	97A29
34	PLATE-RETAINING, Bearing to Connecting Rod	22	PZ1400
35	PLATE-RETAINING, Bearing to Connecting Rod	2	201PZH253
36	SCREW, Bearing to Connecting Rod	48	75B41
37	WIRE	288”	97A29
38	BEARING-ROLLER, Crosshead Pin	3	12BA44
39	PIN-LOCK	3	PZ838
40	SET SCREW	3	76F10
41	CROSSHEAD	3	200PZH005
42	PIN-CROSSHEAD	3	200PZH189
43	PLATE-RETAINER, Crosshead Pin	3	200PZH168
44	SCREW, Retainer Plate	18	75AG17
45	WIRE	72”	97A29
46	ROD-EXTENSION	3	300PZH839
47	SCREW, Rod to Crosshead	18	PO701
48	WIRE	36”	97A29
49	PLATE-RETAINER, Oil Stop Head to Frame	6	2014010
50	ADAPTOR, for Manually Rotating Jackshaft	1	2PO1398
51	SCREW, Adapter to Jackshaft	2	655EF050

5000 PSI WIDE BODY™ FLUID CYLINDER & MANIFOLD



Ref Drawing – 317PZG797


FOR LIST OF PARTS SEE PAGE 6

Order by Part Number and Description. Reference Numbers for your convenience only.

FLUID CYLINDER & MANIFOLDS – 5000 PSI

Ref. No.	Name of Part	Qty.	Part No.
	FLUID CYLINDER ASSEMBLY (Includes Reference Numbers 1 thru 5)	3	201PZL2039
1	CYLINDER-FLUID, 5000 PSI	3	205PZL029
2	STUD, Cylinder to Frame (Long)	24	79L188
3	STUD, Cylinder to Frame (Short)	12	79L73
4	STUD, Valve Cover Ring to Cylinder	48	79AL6
5	STUD, Cylinder to Discharge Manifold	12	202PZL110
6	NUT, Cylinder to Frame Stud	48	50B36
7	NUT, Liner Clamp	12	50AQ30
8	NUT, Valve Cover Ring to Cylinder Stud	48	50B34
9	NUT, Cylinder to Discharge Manifold Stud	12	50B34
10	RING-RETAINER, Valve Cover Gasket	6	2011861
11	RING-VALVE COVER	6	2011699
12	GASKET, Valve Cover	6	300PZJ715
13	BUSHING, Suction Valve Guide	9	2007674
14	COVER-VALVE	6	2011860
15	LOCK-COVER	6	300PZG587
	VALVE GUIDE ASSEMBLY, Includes Reference Numbers 13, 16, 17, 18 & 19	3	2011706
16	PLATE-RETAINER	3	2011701
17	GUIDE-VALVE, Suction	3	2011700
18	SCREW, Valve Guide to Retainer Plate	6	655EE06S
19	WASHER-LOCK	6	95W2
20	MANIFOLD-SUCTION	1	200PZH069
21	GASKET, Suction Manifold to Cylinder	3	25BE41
22	SCREW, Suction Manifold to Cylinder	24	655EG08N
23	GASKET, Suction Manifold Flange	1	25C1154N
24	FLANGE, Suction - Weldneck	1	64CU12
25	SCREW, Suction Flange to Manifold	12	75A150
26	NUT, Suction Flange to Manifold	12	50B9
27	MANIFOLD-DISCHARGE	1	200PZH071
28	GASKET, Discharge Manifold to Cylinder	3	25AL35
29	STUD, Discharge Manifold to Discharge Flange	16	209PZL110
30	NUT, Discharge Manifold to Discharge Flange	32	50AW11
31	GASKET, Discharge Manifold Flange	2	25V24
32	FLANGE, Discharge - Weldneck	1	64EB15
33	FLANGE, Discharge, Blind	1	64EB240
34	BOLT-EYE	6	15P5


Order by Part Number and Description. Reference Numbers for your convenience only.



Ref Drawing – 319PZL810

"SELF ADJUSTING" OIL STOP HEAD PACKING ASSEMBLY

Ref. No.	Name of Part	Qty.	Part No.
	OIL STOP HEAD PACKING ASSEMBLY (Includes 1 thru 5)	3	301PZL4073
1	SEAL HOUSING – OIL STOP HEAD	1	300PZL362
2	SEAL HOUSING – OIL STOP HEAD	1	301PZL362
3	RETAINING PLATE – OIL STOP HEAD HOUSING	1	300PZL168
4	SEAL , Oil	2	2011872
5	SCREW	6	655ED08S
6	OIL STOP HEAD with WEEP HOLE	3	300PZH051
7	SCREW	22	655EE080
8	SEAL-FASTENER	24	25F9
9	BAFFLE	3	PZ840
10	GASKET	3	2009634N




Ref Drawing – 327PZL810

STEM GUIDED VALVE – STEEL FITTED
(General Service– 5000 PSI)

Ref. No.	Name of Part	Qty.	Part No.
	WITH **POLYURETHANE** INSERT		
	FLUID VALVE ASSEMBLY	6	202PZL482A
1	SPRING, Valve	6	78H44
2	LOCKNUT, Valve	6	50V27
3	WASHER, Valve	6	201PZL279
4	INSERT, Valve (Polyurethane)	6	201PZL106
5	VALVE-FLUID	6	202PZL482
6	SEAT-VALVE	6	202PZL039

Ref. No.	Name of Part	Qty.	Part No.
	WITH **CARBOXYLATED NITRILE** INSERT		
	FLUID VALVE ASSEMBLY	6	202PZL482B
1	SPRING, Valve	6	78H44
2	LOCKNUT, Valve	6	50V27
3	WASHER, Valve	6	201PZL279
4	INSERT, Valve (Carboxylated Nitrile)	6	202PZL106
5	VALVE-FLUID	6	202PZL482
6	SEAT-VALVE	6	202PZL039

PISTON & LINER ASSEMBLY



Ref Drawing - 304PZG810

FOR LIST OF PARTS SEE PAGE 10

Order by Part Number and Description. Reference Numbers for your convenience only.


PISTON ROD & COUPLING
(General Service – 5000 PSI)

Ref. No.	Name of Part	Qty.	Part No.
	PLUNGER COUPLING ASSEMBLY		
	Includes Ref. Numbers 1 Thru 4	3	200PZJ4065
1	COUPLING, Plunger	6	200PZJ092
2	SCREW, Coupling	12	655EE22S
3	LOCKNUT	12	50AW35
4	ROD-PISTON	3	1PZ183
5	CLAMP, Liner	3	1PV14
6	O-RING	3	25AH1
7	NUT-LOCK	3	50V14
*	WRENCH	1	99L11

STANDARD PISTONS & LINERS

Ref. No.	Name of Part	Qty.	7.00" Part No.	6.50" Part No.	6.25" Part No.	6.00" Part No.	5.50" Part No.	5.00" Part No.	4.50" Part No.	4.00" Part No.
8	LINER-FLUID	3	207PZJ456	200PZJ456	201PZJ456	202PZJ456	203PZJ456	204PZJ456	205PZJ456	206PZJ456
9	GASKET, Liner	3	25AT37	25AT37	25AT37	25AT37	25AT37	25AT37	25AT37	25AT37
10A	PISTON, 1 piece composite (STD)	3	325PZL350	324PZL350	324PZL350	322PZL350	321PZL350	321PZL350	321PZL350	321PZL350
10B	PISTON, High Temperature (BLUE)	3	316PZL350	315PZL350	315PZL350	313PZL350	312PZL350	312PZL350	312PZL350	312PZL350
10C	PISTON, Water Service (Rubber)	3	202TBL045A	201TBL045A	200TBL045A	245TBB045A	243TBB045A	241TBB045A	239TBB045A	231TBK045A

INTERNAL OIL LUBRICATION PIPING



Ref Drawing – 308PZH797


FOR LIST OF PARTS SEE PAGE 12

Order by Part Number and Description. Reference Numbers for your convenience only.

INTERNAL OIL LUBRICATION PIPING

Ref No.	Name of Part	Qty.	Part No.	Ref No.	Name of Part	Qty.	Part No.
1	SCREEN-OIL	1	3WAJ511	20	NIPPLE-PIPE	1	63U12X50
2	ELBOW-PIPE	1	64S12	21	ADAPTOR	1	29Q17
3	NIPPLE-PIPE	1	63H10	22	HOSE ASSEMBLY	1	2009486
4	PUMP-OIL	1	46C21	23	CLAMP, Hose	2	PZ1301
5	BRACKET, Oil Pump Mounting	1	PZ1398	24	SCREW	1	655EF040
6	SCREW, Bracket to Oil Pump	6	655ED04D	25	SCREW, Hose Clamp to Bearing Housing	1	655EG04N
7	WIRE, Bracket to Oil Pump	1FT	97A29	26	TROUGH, Oil Feed	1	2012690
8	BUSHING, Gear (Includes 8A, B & C)	1	22F12SD	27	SCREW, Trough to Frame	2	655EF040
8A	SET SCREW	1		28	ADAPTOR	1	29Q17
8B	WASHER-LOCK	3		29	WASHER	3	95F10
8C	SCREW, Bushing	3		30	ELBOW-PIPE	1	64C5
9	GEAR	1	2013884	31	NIPPLE-PIPE, Oil Feed to Jackshaft Trough	2	63AJ6X84
10	SCREW, Bracket to Frame	4	655EF05D	32	TROUGH, Jackshaft Oil	2	2012519
11	WASHER	4	95U7	33	SCREW	4	655ED03D
12	WIRE, Bracket to Frame	2FT	97A29	34	WIRE, Through to Bearing Housing	8FT	97A29
13	BUSHING-PIPE	1	64E16	35	ELBOW-TUBE	2	86A86
14	ADAPTOR	1	29Q17	36	TUBE, Jackshaft Oil Trough to X-head Slide	16”	85E6A
15	HOSE ASSEMBLY	1	29R13	37	ADAPTOR	2	29Q54
16	TEE-PIPE	1	64G7	38	HOSE ASSEMBLY	2	29R98
17	PRESSURE RELIEF VALVE	1	90Q22	39	ELBOW-STREET	2	64D4
18	NIPPLE-PIPE	1	63U12X34	40	WASHER	1	95A7
19	UNION	1	64Z10				


Order by Part Number and Description. Reference Numbers for your convenience only.



Ref Drawing - 323PZL810

OIL FILTER


Ref. No.	Name of Part	Qty.	Part No.
1	OIL FILTER ASSEMBLY, Includes Reference Nos. 1A thru 4	1	26C18
1A	ELEMENT ASSEMBLY, Includes Reference No. 3	1	5E30
2	GASKET	1	2109771
3	COVER	1	2109770
4	SCREW	4	75A54
5	GASKET, Filter to Frame	1	25C1788N
6	SCREW, Hex Cap, Filter to Frame	6	655EF050
7	GAUGE, Oil Pressure (80 psi)	1	27P253



SUMP OIL CIRCULATING PUMP

Ref. No.	Name of Part	Qty.	Part No.
	OIL PUMP ASSEMBLY	1	46C21
1	BODY	1	-----
2	HEAD	1	-----
3	COVER	1	-----
4	GASKET	1	2010024
5	KEY, Drive	1	-----
6	BEARING, Shaft	2	2010025
7	RING, Snap	1	-----
8	BEARING, Thrust	1	2010026
9	RING, Snap	1	-----
10	SCREW	2	-----
11	SCREW	4	-----
12	SEAL	1	2010027
13	KEY, Rotor	1	-----
14	RING, Eccentric	1	-----
15	ROTOR SET	1	2010208
16	PIN, Eccentric	2	-----
17	PIN, Locating	1	-----
18	RETAINER	2	-----
19	SCREW	8	-----
20	SHAFT, Standard	1	-----

PISTON ROD WASH PIPING – 5000 PSI



Rer Drawing – 325PZL810

FOR LIST OF PARTS SEE PAGE 16

Order by Part Number and Description. Reference Numbers for your convenience only.


PISTON ROD WASH PIPING
(General Service – 5000 PSI)

Ref No.	Name of Part	Qty.	Part No.
1	TANK, Rod Wash Recovery	1	2012639
2	COVER, Rod Wash Tank	1	2012655
3	NUT-WING	2	50H1
4	SCREW, Rod Wash Tank to Skid	4	75LM268
5	PLUG-PIPE	1	64A6
6	PLUG-PIPE	2	64A7
7	SCREEN-OIL	1	2WAJ511
8	NIPPLE-PIPE	1	63H25
9	UNION-HAMMER	1	64EB1
10	NIPPLE-PIPE	3	63H25
11	VALVE, Ball	2	90AR299
12	TEE-PIPE	1	64G8G
13	ADAPTOR-HOSE	1	29Q9
14	HYDRAULIC HOSE ASSEMBLY	1	2009247
15	PUMP, Rod Wash, (See Page 17)		
	Includes Reference Number 17	1	CA122
16	SCREW, Rod Wash Pump to Skid	4	75LM51
17	KEY	1	35B4
18	BUSHING-SHEAVE	1	22E16B
19	SHEAVE	1	73K1A30
	SHEAVE ASSEMBLY (Items 20 & 21)	1	2012669
20	SHEAVE	1	2012521
21	SCREW-SET, Sheave	2	76F30
22	BELT	1	13C28
23	ADAPTOR-HOSE	1	29Q10
24	HYDRAULIC HOSE ASSEMBLY	1	2009247
25	ADAPTOR-HOSE	1	29Q27
26	REDUCER-PIPE	1	64N3
27	NIPPLE-PIPE	1	63G1
28	VALVE, Ball	1	90A35
29	NIPPLE-PIPE	1	63G1
30	ELBOW-PIPE	1	64C5
31	NIPPLE-PIPE	1	63G9
32	TEE-PIPE	3	64P39
33	NIPPLE-PIPE	2	63N12X150
34	PLUG-PIPE	1	64A5
35	HYDRAULIC HOSE ASSEMBLY	3	29R30
36	CLAMP, Pipe	2	98H5
37	SCREW	2	75LM47
38	ADAPTOR-HOSE	3	29Q83
39	COUPLING-PIPE	3	64BK3
40	BAFFLE	3	1PZ840
41	NUT-ACORN	6	50Q30
42	NIPPLE-PIPE	1	63L31
43	ELBOW-PIPE	1	64C9
44	NIPPLE-PIPE	1	63AJ32X60
*	PLATE, Rod Wash Pump to Skid	1	201PZG247
*	SCREW, Rod Wash Pump to Skid	4	75LM268

* NOT SHOWN

Order by Part Number and Description. Reference Numbers for your convenience only.

PISTON ROD WASH PUMP




Ref Drawing – 328PZL810

Ref. No.	Name of Part	Qty.	Part No.
	PUMP ASSEMBLY, Includes All Parts Shown	1	CA122
1	HOUSING, Impeller	1	C1K2A1
2	PLUG-PIPE	2	64AA6
3	COCK, Drain	1	90C31
	IMPELLER ASSEMBLY, Includes Items 4, 5 & 6	1	C1K1A1A
4	IMPELLER	1	C1K1A1
5	SHAFT	1	C1H5C1
6	PIN	1	62R140
7	KEY	1	35B4
8	PACKING-SEAL	1	60BT11
9	GASKET	1	25D212
10	FRAME	1	C1H4A2
11	SCREW	8	75A130
12	BEARING, Inner & Outer That Includes Snap Rings	2	12AK3

Order by Part Number and Description. Reference Numbers for your convenience only.


HEAT EXCHANGER GROUP (Optional)



Ref Drawing – 302PZG810

Ref No.	Name of Part	Qty.	Part No.
	HEAT EXCHANGER GROUP, Includes All Parts Shown		
1	HYDRAULIC HOSE ASSEMBLY	1	29N1
2	ADAPTOR, Hose	1	29Q17
3	COUPLING-PIPE	1	64BK5
4	NIPPLE-PIPE	1	63G1
5	BUSHING-PIPE	2	64E16
6	CONNECTOR, Frame	2	78AUX113
7	ADAPTOR, Hose	4	29Q10
8	HYDRAULIC HOSE ASSEMBLY	1	2009270
9	HYDRAULIC HOSE ASSEMBLY	1	29Z2
10	BUSHING-PIPE	2	64E11
11	HEAT EXCHANGER	1	2013457
12	SCREW	4	75LM268
13	BUSHING-PIPE	2	64E29
14	NIPPLE-PIPE	3	63F21
15	ELBOW-PIPE	2	64C4
16	NIPPLE-PIPE	2	63AJ8X40
17	HOSE, Oil Proof	2 FT	R14G
18	CLAMP, Hose	2	29B31
19	UNION-PIPE	1	64Z3
20	VALVE, Thermostat	1	90K165
*	PLUG (zinc), Protective	1	2008076

Order by Part Number and Description. Reference Numbers for your convenience only.



Ref Drawing – 316PZG797

VALVE SEAT PULLER (OPTIONAL)


Ref No.	Name of Part	Qty.	Part No.
	VALVE SEAT PULLER ASSEMBLY	1	100E12
	Includes Items 1 thru 11, plus Carrying Case		
1	JACK, Hydraulic	1	2116728
2	STEM, Center	1	2117314
3	NUT, Center Stem	1	2117315
4	BASE, Puller H Bar	1	2116727
5	BUSHING, Center	1	2117316
*	BUSHING, Center	1	2117317
6	HYDRAULIC HOSE	1	2117318
7	PUMP, Hydraulic	1	2117319
8	ADAPTOR, Gauge	1	2117320
9	COUPLER, Quick	1	2117321
10	COUPLER, Gauge	1	2117322
11	GUAGE, 170 Ton	1	2117323
*	CARRYING CASE	1	2117055
	Puller heads are not included with 100E12 assembly.		
12	PULLER HEAD, for Center Guided Valve Seat	1	100E13 **
*	PULLER HEAD, for Full Opening Valve Seat	1	300PZL219
*	Not Shown		
**	Shown on Drawing		

OPTIONAL EQUIPMENT

Name of Part	Qty.	Part No.
BAR, Valve Cover Tightening	1	62L62
PIN, Valve Cover Tightening Bar	1	2009526
HYDRIL DAMPENER (K20-5000)	1	186511
HOSE, For Charging HYDRIL Dampener	1	200OPA127
TOOL, Piston Rod Nut Removal	1	200PZL074
PRESSURE GAUGE GROUP, Includes Next 3 Items:	1	PZL75283
GAUGE (0 - 6000 PSI)	1	27P70
NIPPLE	1	63V32X60
ELBOW	1	64EB241
PRESSURE RELIEF VALVE GROUP, Includes Next 4 Items:	1	PZL75284
PRESSURE RELIEF VALVE, Shear Type (500 to 5000 PSI)	1	5829653
NIPPLE-PIPE	1	63V48X60
ELBOW-PIPE	1	64EB242
ELBOW, STREET	1	64D14
DISCHARGE BLOCK & BLOCK SUPPORT GROUP, Includes: The 301PZG4067 and PZJ74823 Groups	1	PZJ75285
DISCHARGE BLOCK GROUP, Includes Next 6 Items:	1	301PZG4067
GASKET	2	25V24
GASKET	2	25V17
FLANGE	1	191161
FLANGE	1	64EB240
FLANGE	1	64EB50
DISCHARGE BLOCK ASSEMBLY, Includes Next 5 Items:	1	300PZG4067
DISCHARGE BLOCK	1	205PZL231
STUD	24	206PZL110
NUT	24	50AW11
STUD	16	208PZL110
NUT	16	50AW13
SUPPORT GROUP ASSEMBLY, Includes Next 3 Items:	2	PZJ74823
BASE	1	195100
BASE	2	5015475
SUPPORT (Includes the next four items)	2	201845T2
SCREW	2	201853
NUT	2	50W12
PIN	2	62R98
NIPPLE	1	201846
SCREW	1	655EJ200

GARDNER DENVER PUMP UNIT RECORD

The following unit identification plate is provided as a convenience to you, our valued Gardner Denver customer. Please take the time to copy all the information from the actual nameplate on your unit. The model number, date manufactured and serial number will be required when contacting the company or your distributor for information or replacement parts.



Ref. Drawing – 200OPA496

Gardner Denver

Specifications subject to change without notice.
Copyright © 2006 Gardner Denver, Inc. DJC Litho in U.S.A.
http://www.gardnerdenver.com pumps@gardnerdenver.com

For additional information contact your local distributor or

Gardner Denver - Fluid Transfer Division,
1800 Gardner Expressway, Quincy, Illinois 62301
Customer Service Department Telephone:
(800) 682-9868 FAX: (217) 223-1581

For Domestic parts information Contact:
Gardner Denver – Fluid Transfer Division,
2200 South Prospect, Oklahoma City, OK. 73129
Telephone: (405) 677-5736 FAX: (405) 677-5807